


# 18X一体机芯接线手册 V1.0

## 接口定义:

**Zoom Lens interface :**  
Zoom lens control interface



- 电源网络接口 :**
- 1.DC12V
  - 2.GND
  - 3.RJ45\_1(TX+)
  - 4.RJ45\_2(TX-)
  - 5.RJ45\_3(RX+)
  - 6.RJ45-6(RX-)
  - 7.Link Lamp
  - 8.ACT Lamp

**主板接口**

- 调试接口 :**
1. UART0\_TX
  2. UART0\_RX
  3. GND

- 电源网络接口 :**
- 1.DC12V
  - 2.GND
  - 3.RJ45\_1(TX+)
  - 4.RJ45\_2(TX-)
  - 5.RJ45\_3(RX+)
  - 6.RJ45-6(RX-)
  - 7.Link Lamp
  - 8.ACT Lamp